



RED DC+48V
 Black DC-48V

Green DC+24V
 Yellow DC-24V

White Lockup/Work
 Connect to DC-24V to work
 OFF/Disconnect to Lockup

FREX HyperAXIS Wiring Diagram of POWER