
DIY USB to RS485 adapter v1.1
Transmit Led
74HC32
FT232RL
www.Sparkfun.com
FT232R Breakout v3
USB
DC Connector
Power JP
Pull down
Pull up
Terminate
DIP SW
Jumper Wire
Receive Led
LM7805
1N4001
7-30v
www.x-simulator.de